lunorre.co
Info@Lunorre.co


SPECIFICATION AND INSTALLATION GUIDE

# Amara Stainless Steel Table Lamp With Fabric Shade

A polished stainless steel table lamp with a fabric shade and a simple dome silhouette. It plugs into a standard US outlet and suits a nightstand, console or desk. This guide covers specifications, sizing, assembly, everyday use and care.








| 14.3" | 24.4" | E26 | 59" | 4 |
|---|---|---|---|---|
| shade diameter | overall height | standard screw base | cord with switch | finish pairings |
| 36.5 cm | 62 cm | LED or Edison | 150 cm | gold or chrome |

## 01 SPECIFICATIONS

| | |
|---|---|
| Size | Diameter 14.3" x H 24.4" (36.5 x 62 cm) |
| Materials | Stainless steel, fabric, metal |
| Finishes | Gold and Black, Gold and White, Chrome and Black, Chrome and White |
| Placement | Tabletop, indoor |

| | |
|---|---|
| Supply | 110 to 120 V, US plug |
| Bulb | E26 standard screw base, LED or Edison |
| Switch | Push button switch on the cord |
| Dimming | Not dimmable |
| Cord | 59" (150 cm) |

## 02 DIMENSIONS




**Footprint.** The shade is 14.3" (36.5 cm) across, so allow a surface at least that wide.

**Height.** 24.4" (62 cm) tall, a comfortable reading height on most nightstands and desks.

Dimensions are nominal and may vary slightly.


## 03 IN THE BOX

- Stainless steel lamp base with cord and switch
- Fabric shade
- Shade fitting hardware
- Instruction sheet

## 04 WHAT YOU NEED

- An E26 LED or Edison bulb
- A nearby 110 to 120 V outlet

## 05 INSTALLATION




Assembly diagram: 1 shade holder and bulb, 2 fitting the shade

**1 Unpack and set the base**
Place the base on a flat, stable surface near an outlet.

**2 Fit the shade holder and bulb**
Attach the shade holder at the top of the stem and screw an E26 bulb into the socket. (Diagram step 1)

**3 Fit the shade**
Lower the fabric shade onto the holder and secure it at the top. (Diagram step 2)

**4 Plug in and switch on**
Plug into a 110 to 120 V outlet and press the push button switch on the cord.

## 06 EVERYDAY USE

| | |
|---|---|
| On and off | Push button switch on the cord |
| Dimming | Not dimmable |
| Bulb | E26 base; choose a warm LED for a soft glow |

## 07 CARE

- Unplug and let the bulb cool before cleaning.
- Wipe the steel with a soft dry cloth to keep the polish bright.
- Dust the fabric shade with a soft brush or lint roller.

## 08 TROUBLESHOOTING

| If | **Try this** |
|---|---|
| Lamp does not turn on | Check the outlet, the bulb and that the bulb is screwed fully into the socket. |
| Shade sits crooked | Loosen the top fitting, center the shade and tighten again. |

## 09 SAFETY AND REQUIREMENTS

- Plug in lamp for 110 to 120 V US outlets. Do not modify the plug or use it with a damaged cord.
- Indoor, dry locations only.
- Keep the cord out of walkways and away from heat sources.
- Unplug before changing the bulb or cleaning.

Dimensions and performance figures are nominal and subject to manufacturing tolerance. Questions before or after installation: Info@Lunorre.co, +13313065081. Lunorre, lunorre.co